543E/ECP

OUTPUT MIXER AUX-SEND/RETURN EXPANDER

Level controls for
FX-sends 1–4

OUTPUT MIXER EXPANDER

FX SEND 1 CV IN

FX SEND 2 CV IN

FX SEND 3 CV IN

FX SEND 4 CV IN

Control voltage
inputs for
FX-sends 1–4

Level controls for
FX-returns L–R

RETURN L CV IN

RETURN R CV IN

Control voltage
inputs for
FX-returns
left/right

FX SEND OUTPUT

Audio input
for FX-send

FX RETURN IN L   FX RETURN IN R

Audio inputs
for FX-returns

MODULAR 543 E

The M543 E and M543 E CP are expander modules to upgrade the M543/M543CP output mixer modules by a 4-channel send/stereo return FX path.

Two or more of these modules can be connected to the mixer modules to have more effects paths.

Level controls for
FX-sends 1–4

Level controls for
FX-returns L–R

OUTPUT MIXER EXPANDER

EFFECT SEND 1   EFFECT SEND 2   EFFECT RETURN L

EFFECT SEND 3   EFFECT SEND 4   EFFECT RETURN R

FX SEND 1 CV   FX SEND 2 CV   FX SEND 3 CV   FX SEND 4 CV   FX RETURN L CV

FX SEND   FX RETURN L   FX RETURN R   FX RETURN R CV

MODULAR 543 E

Control voltage inputs for
FX-returns left/right